

IF IN DOUBT – ASK

WIRING AND FUNCTION

FOR DC POWER SUPPLY: "L" EQUAL "B+" , "N" EQUAL "0"

APPLY POWER SUPPLY: AC 100~230V OR DC 12V~48V TO "L"&"N"

CONNECT SW-A TO START BEACON IN POSITION A

CONNECT SW-B TO START BEACON IN POSITION B

CONNECT SW-C TO START BEACON IN POSITION C

CONNECT SW-D TO START BEACON IN POSITION D

TO ADJUST THE BEACON FLASHING FREQUENCY, PLEASE REFER TO THE INSTRUCTIONS IN THE PRODUCT TECHNICAL MANUAL.

DO NOT SUPPLY AC OR DC POWER TO S0 /S1/ S2

SW-D						
SW-B SW-A	Cable Selection Please select suitable size cable according to the distance between control					
NEUTRAL	room & the terminals and the quantity of equipments used. Normal size for AC power supply cable & N is 1.5mm ² . Normal size for DC pow					
	supply cable L & N 2.5 mm ² . Please select the quantity of control cables (2 to 7) according to the actual					
	requirement. Normal size for control cable is 1mm ² .					
: AS PARTS			MATERIAL: AS PARTS			
EX-TECH WIRING DIAGRAM SL125/SL150 C40 BC-BC-BC-BC IDARD WIRING NOT RESISTOR(S) NO DIODE(S)						
THE WRITTEN S		00/121	e@a3 S	DWG NG	12/A3	2

Н